


For Home Cockpit Building Purposes Only

For Home Cockpit Building Purposes Only



**ACP**



**PIN-OUT**

**SWITCHES :**

- 5/36 - VHF1 BT SW
- 7/36 - VHF2 BT SW
- 13/36 - VHF3 BT SW
- 10/3 - VOICE BT SW
- 20/36 - HF 1 BT SW
- 29/36 - HF 2 BT SW
- 27/3 - RESET SW
- 34/36 - INT BT SW
- 38/36 - CAB BT SW
- 31/36 - PA BT SW
- 3/1 - INT SW
- 3/2 - RAD SW

**LIGHTS :**

- 4/15 - VHF1 LINES LT
- 6/15 - VHF1 CALL LT
- 8/15 - VHF2 LINES LT
- 9/26 - VHF2 CALL LT
- 14/15 - VHF3 LINES LT
- 12/26 - VHF3 CALL LT
- 11/15 - VOICE ON LT
- 21/15 - HF1 LINES LT
- 22/26 - HF1 CALL LT
- 30/15 - HF2 LINES LT
- 28/26 - HF2 CALL LT
- 35/15 - INT LINES LT
- 33/26 - INT CALL LT
- 39/15 - CAB LINES LT
- 37/26 - CAB CALL LT
- 32/15 - PA LINES LT
- 43/41 - BACK LT
- POWER (0-5V)

**ACP inner Connector**

